


# Compass Taillight



## Frame Preparation

- ✦ This light should be installed by a competent framebuilder.
- ✦ Thread the small tube (1) into the larger frame braze-on (2).
- ✦ The threaded portion should be barely hidden inside the braze-on.
- ✦ Tack the tube in place inside the braze-on.
- ✦ Test that the light still will screw all the way into the braze-on from the other side.
- ✦ Drill a 3.5 mm hole in the back of the seat tube.
- ✦ Insert the braze-on and braze it in place on the seat tube.

## Installing the Light

- ✦ Feed the wire through the braze-on into the seat tube.
- ✦ Retrieve the wire through the top of the seat tube
- ✦ Carefull pull the wire through the seat tube until the light touches the braze-ons.
- ✦ Screw the light into the braze-on. Turn the wire at the exit of the seat tube as you screw in the light. This prevents wind-up of the wire inside the seat tube.

## Important!

The light is designed to be sealed and waterproof, but it is not designed to be in a constant spray of water. If you ride in the rain, use a rear fender to prevent spray on the light. If you carry your bike on a car rooftop, have the light face backward.

## Warranty

Compass Bicycles warranties this taillight for 2 years for defects in materials and workmanship. The sole remedy is repair or replacement, at Compass Bicycles Ltd.'s discretion. Not covered under the warranty are:

- ✦ Attachment cables that are abraded or cut.
- ✦ Moisture damage due to being subjected to a constant spray of water.